


FOOD DEHYDRATOR

Instruction Manual

Model No.: RAWDH8



IMPORTANT:

Before using this product, please read and understand this instruction manual carefully, and keep it in a safe place; this product is only for use in homes or similar places.

Danger:

Do not immerse the base in water or any other liquid, and do not rinse under the tap.
Do not use this product to dry liquid foods.


Please read carefully and keep the instruction well

WARNINGS:

- Before connecting the product to the power supply, please check whether the voltage marked on the product is consistent with the local power supply voltage, and all components are installed correctly.
- Do not allow children or persons with intellectual disabilities to use this product unattended.
- This product should be used on a stable table, not on an inclined or blanketed table.
- When going out or not in use for a long time, please be sure to unplug the power plug from the socket.
- After the first power-on, there is a smell, please continue to use it if it is not abnormal.
- Do not operate or plug in or out the power plug with wet hands to prevent electric shock.
- Do not use this product to dry liquid foods.
- Do not use bleach or chemical disinfectant solutions/tablets in this product.
- Do not use steel wool, abrasive cleaners, or corrosive liquids (such as acetone or alcohol) to clean the product.
- The longest continuous use time should not exceed 72 hours each time, so as not to affect the service life of the dryer.
- Do not use this product if the power cord, plug or other accessories are damaged.
- If the power cord is damaged, in order to avoid danger, it must be replaced by professionals from the manufacturer, its maintenance department or similar departments.
- Please do not use accessories or components made by other manufacturers or other manufacturers that are not recommended.
- It is forbidden to modify or lengthen the power cord of this product in any way.
- It is forbidden to use this product outdoors, or to use this product for other purposes.
- All accessories are only suitable for the use of this product. It is forbidden to be used for other purposes or on other similar products to avoid danger.
- It is forbidden to yank the power cord of the product or tie the power cord to an object at a favorable angle.
- Non-professionals are not allowed to disassemble any internal components to avoid danger.
- It is forbidden to move this product when it is plugged in. You can turn it off when necessary, unplug the power plug, and move it to a suitable location.
- If you have any questions, please contact the relevant service center or dealer for help.
- Before cleaning the product, you must first unplug the power plug and let it cool down.
- Do not place any food (including water and seasonings and food) on the saucepan
- Do not put any objects into the hot air outlet hole.
- Never use a microwave oven to heat any other parts of the product.

PRODUCT DESCRIPTION:

Control panel: touch button operation



- Turn on: After the power is turned on, all the indicator lights flash once and then go out, and at the same time a short "Di" sound, then only the power button indicator light keeps on, all other patterns and digital tube lights are off, and it enters the "standby state". If there is no operation, the "standby state" will be kept continuously.

- Under the "standby" state, short press the "⏻" key to enter the "wake-up" state. Short press the "⏻" key again to enter the "working" state.

- When under "working" status, the digital tube countdown will display the countdown in real time, and the corresponding function key can be touched during the process, and at the same time, the corresponding function adjustment will be entered (the function indicator light is always on and the digital tube is flashing) at the same time. The corresponding function continues to operate, and automatically enters the "working" state 3 seconds after the setting is completed.

- During the "working" state, short press the "⏻" key to enter the "standby" state.

- In the "wake-up" state, if there is no operation, it will enter the "standby" state after 5 minutes; if there are other operations, the time will be delayed for 5 minutes and enter the "standby" state.

- In any state, as long as the "💡" icon is always on, short press "💡" to switch the lamp on and off.

- This machine has a memory function.

- Long press "⬆️" to quickly increase the time or temperature preset value.

- Long press "⬇️" to quickly decrease the time or temperature preset value.

- In any state, as long as "🌡️" is always on, press and hold the "🌡️" key for 3 seconds, and the displayed temperature will switch between "°F" and "°C"; if you want to switch again, you need to press

and hold again "  " key for 3 seconds.

When the display is "°C", it can be customized between 30°C and 75°C. The temperature variable unit is 5°C.

When "°F" is displayed, it can be customized from 86°F to 167°F. The temperature variable unit is 9°F.


FAULT PROTECTION:

If an NTC failure is detected during the "working" state, the heating must be stopped immediately, and the display shows "E1" with three short "Di" beeps, the motor will stop after a delay of 10 seconds; then it will enter the "wake-up" state.

If an NTC failure is detected during the "wake-up" state, the display shows "E1" with three short beeps. After 5 minutes, it enters the "standby" state and keep it.

In any states, if NTC detects the temperature \geq "85" degrees (no need to compensate), it must stop heating immediately, and the display shows "E2" with three short beeps; the motor will stop after a delay of 10 seconds, Enter the "standby" state after 5 minutes.

ACCESSORIES AND INSTRUCTIONS:



- A. Mesh sheet: It is used to hold small foods that need to be dried and dehydrated.
- B. Drying Trays: It is used to hold food that needs to be dried and dehydrated.
- C. Drip Tray: Used to support the fines and fallen juice of the upper layer of food.
- D. Door: It is used to seal the outlet of hot air and bottom air.
- E. Control Panel: Used to control the work of the machine.
- F. Housing: Metal material.

ACCESSORY DISASSEMBLY METHOD:

- A. Take out the machine.
- B. Open the door.
- C. Take out the drying trays or mesh sheet.
- D. Put the food drying trays (if you need to use mesh sheet, please put the mesh sheet on the empty trays) back to the machine.
- E. Close the door.
- F. Insert the plug into the socket.
- G. Operate the control panel and select functions

HOW TO USE THE FUNCTION:

1. Drying function:

- 1.1 The time can only be adjusted within 1 hour to 48 hours. The single adjustment time is "30

minutes", and the time or temperature is increased rapidly when long-pressing.

1.2 The temperature can only be adjusted within 30~75°C. The single-time adjustment temperature is "5°C" (US standard 5°F), and the time or temperature is increased rapidly when long-pressing.

1.3 Turn on: After the power is turned on, all the indicator lights flash once and then go out, and at the same time, there is a short "Di" sound, then only the power button indicator light keeps on, all other patterns and digital tube lights are off, and it enters the "standby state" . If there is no operation, the "standby state" will be kept continuously.

Under the "standby" state, short press the "⏻" key to enter the "wake-up state". Short press the "⏻" key again to enter the "working state". When the "working status" is in progress, the digital tube countdown will display the countdown in real time, and the corresponding function key can be touched during the process, and at the same time, the corresponding function adjustment will be entered (the function indicator light is always on and the digital tube is flashing) at the same time. The corresponding function continues to operate, and automatically enters the "working state" 3 seconds after the setting is completed.

Under the "working state", short press the "⏻" key to enter the "standby state".

Under the "wake-up state", if there is no operation, it will enter the "standby state" after 5 minutes; if there are other operations, the time will be delayed for 5 minutes and enter the "standby state".

Under any states, as long as the "💡" icon is always on, short press "💡" to switch the lamp on and off.

2. Food processing:

2.1 Fruit pretreatment:

2.11 Dilute the juice (1/4 cup of juice and 2 cups of water), and soak the food to be dried for about 2 minutes.

(Note: Fruit juice is matched with food, such as apple juice for dried apples.)

2.12 Food processing table:

Food name	Ingredient Specifications	Temp°C	Dry state	Time/hour
Apricot	Cut in half and remove the pits. Cut in half with the dry side facing down	60-65	Soft	18-20
Banana	Peel and cut into 3mm slices	65-70	Crispy	12-14
Fig	Wash, remove stains, and cut into quarters. Dry side down	60-65	Soft	18-20
Kiwi	Wash and cut into 6mm slices	60-65	Soft	8-11
Peach	Wash, peel, core and cut into halves or slices	60-65	Soft	8-17
Pear	Wash, core and peel and cut into circles	60-65	Soft	4-8
Pineapple	Peel, remove the fiber part, and remove the core. Cut into 6mm slices	60-65	Soft	11-18
Rhubarb	Wash and cut into a length of 25 mm	60-65	Soft	6-10
Strawberry	Wash and cut into 6mm slices	60-65	Soft	7-15
Watermelon	Peel, cut into wedges, and remove seeds. Cut into 10 mm pieces.	60-65	Soft and sticky	8-10
Pitaya	Peel and cut into 3mm slices	65-70	Crispy	10-14
Apple	Wash, core and peel and cut into circles	60-65	Soft	7-15

2.2Vegetable pretreatment:

2.21 Treat with steam, boiling water or oil. Recommended for green legumes, cauliflower, broccoli, asparagus and potatoes.

2.22 Put the prepared vegetables in boiling water for about 3-5 minutes, drain them and put them in a shelf.

2.23 Soak the vegetables in lemon juice for about 2 minutes.

Food name	Ingredient Specifications	Temp°C	Dry state	Time/hour
Artichoke	Cut into 8mm strips and cook for about 10 minutes	50-55	fragile	6-14
Leguminosae	Cut and steam until translucent and even, spread on a fine mesh dish	45-55	Hard/fragile	10-18
Brussels Leaf	Pure leaves without rhizomes	50-55	Fragile	8-30
Cauliflower	Steamed softly, cut	50-55	Tough	6-16
Celery	Cut 7mm thick slices	50-55	Fragile	6-14
Chinese chives	cut	50-55	Fragile	6-10
Garlic	Peeled and sliced	50-55	Fragile	6-16
Black pepper	entire	65-70	Fragile	8-14
Onion	slice	50-55	Fragile	8-14
Pea	Steam for 3-5 minutes	65-70	Fragile	8-14
Spinach	Steamed till withered	50-55	Fragile	6-16
Asparagus	After washing, cut into 25mm pieces	50-55	Crispy	4-6
Beet	Steam, cool, remove roots and heads; cut into 25 mm pieces	50-55	Crispy	9-12
Beetroot	Take out the 10mm top, preferably peel it thoroughly, and then cut into 5mm slices.	50-55	Soft	9-12
Brocoli	Cut open and boil soft, cut into 10mm pieces	50-55	Crispy	10-14
Cabbage	Wash and cut into 3 mm long strips	50-55	Crispy	8-11
Carrot	Trim the top and bottom and shave the skin clean. Steamed softly and cut into 3mm thick slices	50-55	Flexible	7-11
Corn	Cut the corn kernels from the corncob and spread them on the mesh sheet	50-55	Crispy	7-10
Cucumber	Wash and cut into 3mm slices	50-55	Flexible	4-8
Eggplant	Wash and peel, cut into 6mm slices	50-55	Flexible	4-8
Mushroom	Wash and cut into 8mm slices	50-55	Flexible	4-7
Radish	Scrub and steam bleach (if needed) and cut into 8mm slices	50-55	Soft/Flexible	7-11
Chili	Wash and remove the seeds and white parts. Cut into 6mm long strips or rings	50-55	Flexible	4-8
Potato	Wash and peel. Steam for about 4-6 minutes until soft. Cut into 6mm slices.	50-55	Crispy/soft	7-13
Pumpkin	Wash and cut into 6mm slices	50-55	Flexible	10-14
Tomato	After washing, cut into 6mm rounds	50-55	Flexible	10-14
Squash	Wash and cut into 5mm slices	50-55	Crispy	7-11
Sweet potato	Wash and peel. Steam for 4-6 minutes. Cut into 6mm slices.	50-55	Crispy/soft	7-13

2.3 Food pretreatment such as meat and fish:

2.31 Lean meat (without fat and oil layer): It is recommended to marinate the meat before drying to maintain its natural taste and make it tender. Salt should be used when marinating to help absorb water from the meat and to keep it fresh. Marinating standard: 1/2 cup of bean paste; 1 garlic, mashed; 2 tablespoons of brown sugar; 2 tablespoons of ketchup; 1/2 cup of Worcestershire sauce; 5/4 teaspoons of salt; 1 /2 teaspoon of onion powder; 1/2 teaspoon of pepper; mix all the above ingredients. The meat is cut into small cubes and put into the machine.

2.32 Poultry meat: All poultry meat must be cooked before drying. Steamed or grilled is best.

2.33 Fish: It is recommended to steam or roast before drying (bake in the oven at 200 degrees for 20 minutes).

Food name	Ingredient Specifications	Temp°C	Dry state	Time/hour
Jerky	Use lean meat to remove as much fat as possible, as fat will deteriorate over time. Cut into 6mm thick slices and place on the shelf	60-70	Flexible	7-8
Nuts and dried fruits	Spread evenly on the mesh sheet	50-55	Hard/Fragile	8-14

2.4 Vanilla and other pretreatment:

2.41 Rinse and shake off excess water, and remove spoiled leaves. Spread the vanilla loosely on the shelf.

Food name	Ingredient Specifications	Temp°C	Dry state	Time/hour
Vanilla/herb	Spread the ingredients loosely on the shelf instead of stacking them	40-50	Soft/Fragile	8-12
Scented tea	Spread the scented tea loosely on the shelf, do not stack	30-40	Flexible	10-18

CLEANING AND MAINTENANCE:

1. Please turn off the machine before cleaning, unplug the power plug, and it must be dry before the next use.
2. Please take out the accessories according to the method of assembly and disassembly, and clean them separately.
3. The product should be cleaned immediately after each use of the product.
4. Do not immerse the host in water or other liquids, and do not rinse the host under the tap.
5. Do not use bleach or chemical disinfectant solutions/tablets in this product.
6. Do not use steel wire balls, abrasive cleaners or corrosive liquids (such as gasoline, acetone or alcohol) to clean the product.
7. After cleaning, dry the host and all accessories.
8. Please clean relevant accessories in time after use.


COMMON PROBLEM ANALYSIS:

1. The drier does not work / does not heat up?
 - 1.1 Check whether the socket and the power cord plug are well connected.
 - 1.2 Check whether the power cord is in good condition. If the power cord is damaged, it must be replaced by the manufacturer or its maintenance department or similar professionals to avoid danger.
2. The indicator light does not light up:
 - 2.1 Is there a power outage?
 - 2.2 Is the power cord plugged into the socket? Is the power outlet turned off?

Remark:

After analyzing the above phenomena, the fault still cannot be eliminated, please contact the company's maintenance point or the dealer. It is strictly forbidden for non-professionals to disassemble the machine by themselves.

Product specifications:

Product name	Food Dehydrator
Product number	RAWDH8
Rated voltage	230V
Rated frequency	50/60Hz
Rated power	600W
Size (L x W x H)	400x340x310mm
Picture	

Tips:

●If the above content is inconsistent with the actual product due to model or parts changes, please refer to the actual product without prior notice. Please understand!